

Curling Hack Installation

The hacks come as a set of 2 and also come with 4 GRK screws. Once your rink has been laid out and you decide where you want the hacks behind the rings, then position the hacks so they are aligned directly behind the button and are square with the button at the other end.

You'll need an impact driver or regular drill, a 6' long by 3/16" diameter drill bit and a GRK bit.

Using a 6" or longer drill bit with a diameter of 3/16" drill 2 holes into the ice using the holes provided in the base of the hack as a guide. We suggest you do four pilot holes in the ice using the base as a guide and then drilling the holes in the ice with the hack placed to one side.

Once done, then screw the hack into the ice using the 6" GRK bits provided. When doing this, screw the GRK in an inch at a time. Then reversing the GRK screw out to clear the hole.

Once both GRKs are installed, then mix up some slush and pack it around the base of the bottom plate. Let it freeze and you have a solid hack.

To remove the hacks, chip away the frozen slush from the base, remove the GRK screws and tap the hack loose from the ice.